

Call Minder

An advanced answer machine service on your phone, that can also be accessed from your mobile.

To enter the Call Minder menu dial the following from your handset:

1 **5** **7** **1**
JKL PQRS

| Main Menu | Sub Menu |
|----------------------|----------------------------------|
| 1 Messages | 1 Replay |
| | 2 ABC Save |
| | 3 DEF Delete |
| | 7 PQRS Skip Back |
| | 8 TUV Pause |
| | 9 WXYZ Skip forward |
| | 0 + Return Call |

| Main Menu | Sub Menu |
|-------------------------------------|---|
| 2 ABC Personal Options | 1 Greeting Message |
| | 2 ABC PIN |
| | 3 DEF Calling Options |
| | 6 MNO Link/Unlink Mobile |
| | 7 PQRS Callers who left no message |

| Main Menu | Sub Menu |
|--|------------------------------|
| 4 GHI Callers Who Left No Message | 1 Hear Again |
| | 2 ABC Skip |
| | 3 DEF Delete |
| | 0 + Return Call |